



Installation Instructions for
Honda CB750 79-82, CB900 80-82
CB1100 82-83 & CB750 Nighthawk 82-83
All Models F & Custom
001-2601, 201-2601, 501-2601 & 801-2601

1. Start by removing the stock OEM exhaust system from the motorcycle.
2. Install the new gaskets in the cylinder head. Note: Exhaust Gaskets are not supplied by MAC. You will need to order the gaskets from your local Honda Dealer.
3. Install the head pipe into the cylinder head and attach it by using the stock hardware and the exhaust clips supplied by MAC. Note: Do not tighten the head pipe at this time.
4. Install the Exhaust clamp provided in the kit to the MAC muffler.
5. Install the MAC muffler onto the head pipe. Note Do not tighten at this time.
6. Using the bolt provided in the kit, install it on the top side of the MAC muffler and attach the bracket to the muffler using the smaller hole in the bracket.
7. Install the bracket to the back side of the passenger footpeg and using the stock nut to fasten the bolt to the motorcycle.
8. Align the MAC Exhaust system and start by tightening the head pipe first. Note: You will tighten the header bolts to stock specs. Do not over tighten.
9. Next you will tighten the bolt holding the muffler in place and last you will tighten the muffler clamp. When tightening the muffler clamp make sure that the clamp is at the end of the muffler to make a good seal.
10. Next you will install the centerstand stop bracket ("L" bracket), if your centerstand is removed skip to step #15.
11. To install the centerstand stop you will need to have the motorcycle on the sidestand.
12. Install the centerstand stop bracket on the left side of the motorcycle to the passenger footpeg facing in towards the tire.
13. Let the centerstand come up and make contact with the bracket and tighten.
14. Start the motorcycle and check for any leaks. If leaks are present, loosen, realign and tighten.
15. You have complete the install of the MAC 4 into 1 Exhaust System.